



Note:

Jet pump 1 is connected to water diverter valve 1, which is connected to group A water distributor and D swim jet. Group A water distributor is connected to the A1 and A2 jets, Jet pump 2 is connected to the water diverter valve 2, which is connected to the group B water distributor and the E swim jet. Group B water distributor is connected to the B1; B2 and B3 nozzles. Jet Pump 3 is connected to the F swim jet. The circulation pump is connected to the Group C water distributor, which is connected to the C1 nozzle, waterfall, and UV sterilizer; G air valve is connected to the A1; A2 and C1 jets. H air valve is connected to the B1; B2 and B3 jets. I air valve is connected to the D and E swim jet. J air valve is connected to F swim jet. The dotted circle indicates the range of the point. The waterfall is controlled by a water inlet switch; The air blower is connected to all bubble jets and aromatherapy tanks; The air blower and waterfall are optional, please pay attention to the configuration and order requirements.

3pcs jet pump+ 1pc circulation pump

ZR6803 Spa Front View